

BLADE 180 CFX HELICOPTER CNC Blade 180 CFX Power package INSTRUCTION

MICROHELI CO., LTD.

COPYRIGHT © 2017 MICROHELI®

1 PRECISION CNC ALUMINUM MAIN ROTOR HUB W/ BUTTON MH-18FX001B



Apply Loctite to all screws

M1.2x3mm Phillips Head Screw


.....x1

M1.6x6mm Phillips Head Screw

.....x1

2.5x5.5x0.4mm Brass Spacer

.....x2



Apply Loctite

CAUTION: Please check your model helicopter carefully before attempt to fly!

REV. 18FX-PWRW-120115-01

01

BLADE 180 CFX HELICOPTER CNC Blade 180 CFX Power package INSTRUCTION

MICROHELI CO., LTD.

COPYRIGHT © 2017 MICROHELI®

2 MAIN BLADE GRIP W/ THRUST BEARING/TITANIUM BALL MH-18FX002



Apply Loctite to all screws

3mm Titanium Ball

.....x2

2.5x5.5x0.6mm Brass Spacer

.....x2

2.5x6x1.8mm Radial Bearing

.....x4

2.5x4.5x1.1mm Aluminum Spacer

.....x2

2.5x5.5x0.7mm Brass Spacer


.....x2

2.5x6x3mm Thrust Bearing

.....x2

M1.6x8mm Cap Screw

.....x2



Apply Loctite

CAUTION: Please check your model helicopter carefully before attempt to fly!

REV. 18FX-PWRW-120115-01

02